

Recommended Spare Parts
Model ZS8 Flameproof Zirconia Oxygen Analyzer

Manufacturer P/N	Cemtrex P/N	Description
K9292CX	20-408-1196	Cold Junction Assembly
K9292DE	20-408-1197	Filter Assembly
E7042BR	20-408-1068	Plate
E7042BQ	20-408-1138	Pipe
E7042DW	20-408-1065	Washer (SUS316 stainless steel)
G7109YC	20-408-1063	Bolt (M5x12, SUS316 stainless steel)
E7042UD	20-408-1137	Cell Assembly (with Japanese introduction sheet)
E7042BS	20-408-1075	Contact
K9470BJ	20-408-1076	Metal O-ring
E7042AY	20-408-1077	Filter
Y9508RU	20-408-1198	Bolt
K9292VA	20-408-1199	Ejector Rc1/4
K9292VB	20-408-1200	Ejector 1/4NPT
K9292DN	20-408-1201	Check Valve Rc1/4
K9292DS	20-408-1202	Check Valve 1/4NPT
K9292BA	20-408-1203	Flame Arrestor Calibration gas. Reference air Inlet. Rc1/4
K9292BB	20-408-1204	Flame Arrestor Calibration gas. Reference air Inlet. 1/4NPT
K9292BU	20-408-1205	Flame Arrestor Reference air outlet Rc1/4
K9292BY	20-408-1206	Flame Arrestor Reference air outlet 1/4NPT
K9291XA	20-408-1207	Packing
Y9635ZU	20-408-1208	Bolt M12x35 SUS
Y9406LS	20-408-1209	Screw
L9801BF	20-408-1150	Washer
K9291DP	20-408-1210	LCD Assembly
L9813VJ	20-408-1211	Clamp
K9291PA	20-408-1212	Display Assembly
K9291QA	20-408-1213	CPU Assembly (for ZS8C-J-5--J'')
K9291QF	20-408-1214	CPU Assembly (for ZS8C-J-8--J'')
K9291QL	20-408-1215	CPU Assembly (for ZS8C-J-3(or 4)--J'')
K9291QB	20-408-1216	CPU Assembly (for ZS8C-J-5--E'')
K9291QG	20-408-1217	CPU Assembly (for ZS8C-J-8--E'')
K9291QM	20-408-1218	CPU Assembly (for ZS8C-J-3(or 4)--E'')
K9291YA	20-408-1219	Controller (ZS8C-J--1--'' only)
K9291YD	20-408-1220	Noise Filter (ZS8C-J-3(or 4)--'' only)
K9291FB	20-408-1221	Bracket (pipe mounting only)
Y9814NU	20-408-1222	Screw
K9291FE	20-408-1223	Flame Arrestor Assembly Rc1/4
K9291FF	20-408-1224	Flame Arrestor Assembly 1/4NPT

Manufacturer P/N	Centrex P/N	Description
G9601AE	20-408-1225	Cable Gland Assembly
G9330DQ	20-408-1226	Plug
K9292TP	20-408-1082	Probe (SiC, L=0.5m)
K9292TQ	20-408-1084	Probe (SiC, L=0.7m)
E7046AL	20-408-1087	Probe (SiC, L=1.0m)
E7046BB	20-408-1088	Probe (SiC, L=1.5m)
K9292TV	20-408-1089	Probe (SUS, L=0.5m)
K9292TW	20-408-1091	Probe (SUS, L=0.7m)
E7046AP	20-408-1094	Probe (SUS, L=1.0m)
E7046AQ	20-408-1095	Probe (SUS, L=1.5m)
K9292TA	20-408-1227	Case (for JIS 10K-100-FF equivalent)
K9292TB	20-408-1228	Case (for ANSI CLASS150-4-RF equivalent)
K9292TC	20-408-1229	Case (for DIN PN10-DN100-A equivalent)
K9292TD	20-408-1230	Case (for DIN PN10-DN100-A equivalent)
K9292UJ	20-408-1231	Gasket
Y9660RU	20-408-1232	Bolt
Y9121BU	20-408-1112	Nut
Y9120WU	20-408-1113	Washer
K9292WA	20-408-1234	Sub Ejector (Rc1/4)
K9292WB	20-408-1235	Sub Ejector (1/4NPT)
E7046FQ	20-408-1106	Gasket
E7046FN	20-408-1107	Plate
Y9825NU	20-408-1108	Bolt
Y9800WU	20-408-1109	Washer
Y9801BU	20-408-1114	Nut
K9292DL	20-408-1236	Gasket
K9292VA	20-408-1199	Main Ejector, Connection Rc1/4 For Detector Use
K9292VB	20-408-1200	Main Ejector, Connection 1/4NPT For Detector Use
K9292WA	20-408-1234	Auxilliary Ejector, Connection Rc1/4 For Probe Adaptor Use
K9292WB	20-408-1235	Auxilliary Ejector, Connection 1/4NPT For Probe Adaptor Use
L9852CB	20-408-1117	Needle Valve, Connection Rc1/4
G7016XH	20-408-1118	Needle Valve, Connection 1/4NPT
E7046EK	20-408-1119	Pressure Gauge, Connection Rc1/4
E7046EV	20-408-1120	Pressure Gauge, Connection 1/4NPT
K9292VE	20-408-1237	Ejector Assembly, Connection Rc1/4 For Detector Use
K9292VF	20-408-1238	Ejector Assembly, Connection 1/4NPT For Detector Use
K9292WC	20-408-1239	Ejector Assembly, Connection Rc1/4 For Probe Adaptor Use
K9292WD	20-408-1240	Ejector Assembly, Connection 1/4NPT For Probe Adaptor Use